

EnSight Tips & Tricks

Did you know...?

2010 Japan EnSight Forum

Aric Meyer

Asia Representative for CEI

Talk Segments

Part 1: Tips and Tricks

Part 2: Color Palettes

Part 3: Introduction EnSight Graphics

Part 4: Python Scripting 'teaser'

Part 1 Outline

- EnSight user directories
- Ways to change settings
 - Preferences
 - Command line parameters
 - Environment variables
- Did you know about...
 - Data reader options?
 - How to load individual parts?
 - Extended CFD variables?


CEI manuals

- Getting Started Manual 88 pages
 - How To Manual 438 pages
 - User Manual 826 pages
 - Interface Manual 358 pages
 - Command Language Manual 1577 pages
-
- These are reference manuals. Users are not expected to read them cover to cover.
 - I hope this presentation gives you useful knowledge about EnSight

EnSight user directories

- For storing personal preferences, macros, user-defined tools, license keys
 - Users may not have access to installation directories
- Default paths of EnSight user directories:
 - Windows Vista and 7:
C:¥Users¥username¥.ensight91
 - Windows (XP and older):
C:¥Documents and Settings¥username¥.ensight91
 - Linux:
~/ensight91
 - Mac:
~/Library/Application Support/EnSight91
- EnSight 9.2 will use .ensight92

Preferences



- Preferences can be set in the menu
Edit -> Preferences
- After a preference is changed, it must be saved to change the default setting
- See detailed info in How To Manual: How To... Set or Modify Preferences

How To ... Set or Modify Preferences




Useful preferences - 1


Color palettes:

- Use continuous palette for per element vars

OFF (default)



ON




Useful preferences - 2

- Command Line Parameters:

- See list of parameters
- Add or remove them

- Data:

- Default data directory
- If starting time step is not specified load:
 - Last (default) or first





Useful preferences - 3

- General user interface: Large parts list

OFF (default)

ON





Useful preferences - 4

- General user interface:
 - Modify and save icon layout...


Most users do not use all of EnSight's features. Turn off the icons you don't use!

Useful preferences - 5

- General user interface:
 - Frame mode allowed
 - Advanced feature for visual rigid body transformations
 - Record part selection in command language by
 - Name or Number (default)
 - Save size and position of main windows
 - Arrange the GUI windows to suit you, then save the layout
- Mouse and keyboard:
 - Assign functions to mouse buttons
- Performance:
 - Abort server operations
 - Set a time limit for operations in EnSight
- Query:
 - Auto Plot Queries

Useful preferences

- Color palettes
 - Use continuous palette for per element colors
- Command Line Parameters
- Data
 - Default data directory
 - If starting time step is not specified look for
- General user interface
 - Large parts list
 - Frame mode allowed
 - Record part selection in command line
 - Modify and save icon layout...
 - Save size and position of main window
- Mouse and keyboard



Command line parameters

- Type manually
- Add to a script
- Set in the preferences
- For a list of command line parameters, see How To Manual: How To... Command Line Start-up Options



Environment Variables

- How to view/set environment variables:
 - Windows Vista and 7:
 - Control Panel -> System -> Advanced -> Environment Variables

- For a list of environment variables, see How To Manual: How To... Use Environment


How To ... Use Environment Variables



Did you know...?

Reader options

- Many data readers have options that can be selected
- In the File Open window:



In Advanced interface:

1. Select reader format in 'Data' tab

2. Change to 'Format options' tab

3. Select options

Options are unique to each reader


- For more information see the User Manual Section 2.3: 'Other Readers'

Individual Part Loading

File Open window

'Advanced interface' tab:


1. Select file format and data file
2. 'Select parts to load...'



Select parts to load...


EnSight's

part loader




- Load individual parts
- group parts
- choose visual representation
 - These settings can also be changed later in EnSight
- Useful for large datasets or when you only want a few parts
- Part loader can also be accessed after data is loaded using File -> Load Parts...
- Can be used to load multiple copies of the same part


Extended CFD Variables



- Automatically compute common CFD variables
- Open the variable calculator



- Open CFD variables window
- Learn more in the How To Manual



Extended CFD Variables

- Specify needed variables
 - Required:
 - Energy
 - and
 - Velocity or momentum
- Check this box to see the new variables in the variables list
- Click 'OK' to compute

Extended CFD Variable Settings

Select a variable and then select the appropriate SET button

Density
Energy
Momentum
FSMACH
ΔI PHA

Density (Can be a constant) Density SET

Total Energy per Unit Volume Energy SET

Ratio of Specific Heats (Can be a constant) 1.4000e+000 SET

Momentum --OR-- Velocity Momentum SET

Freestream Mach # 3.0000e-001

Gas Constant 1.0000e+000

Freestream density 1.0000e+000

Freestream Speed of Sound 1.0000e+000

Show Extended CFD Variables

OK Cancel Help

Extended CFD Variables

- Variables created:
 - Enthalpy
 - Entropy
 - Helicity
 - Mach
 - Pressure
 - ShockPlot3d
 - SonicSpeed
 - Swirl
 - Temperature
 - Vorticity
- and more